



Asus Q302UA-BHI5T20 Fan and Heat Sink Replacement

How to replace an Asus Q302UA-BHI5T20 fan and heat sink.

Written By: Arthur Sperotto



INTRODUCTION


This guide will help you replace the fan and heat sink component of your laptop. You may want to do this if you notice the fan stop working. Be sure to follow this guide in a well lit room on a flat surface. Acquire the necessary tools before hand and have a cup or a magnetic plate to keep track of all the screws.



TOOLS:



- [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Fan and Heat Sink




- Unscrew the ten 10mm Phillips #0 screws.
- Use the plastic opening tool along the side of the laptop to pry open.

Step 2



- Remove the seven 4mm Phillips #0 screws.
- Gently pull the connector.

Step 3



- Lift the heat sink and fan assembly, and you are done!
- ⓘ There maybe a little resistance to being pulled up since the heat sink is attached to the CPU with thermal paste

To reassemble your device, follow these instructions in reverse order.