



ASUS K53E-BBR1 Keyboard Replacement

This guide is intended to demonstrate how to replace a malfunctioning keyboard on the ASUS K53-E-BBR1.

Written By: Paulo Fortes



INTRODUCTION

This guide is intended to demonstrate how to replace a malfunctioning keyboard on the ASUS K53-E-BBR1. You will need an opening tool to remove the keyboard. Also be cautious of the ribbon cable connecting the keyboard to the laptop.

TOOLS:


- [iFixit Opening Tools](#) (1)
-

Step 1 — Keyboard



- Lift the monitor up so that the keyboard is visible.
- You will notice five spots on the top of the keyboard where the iFixit opening tool should be placed.

Step 2



- Use the iFixit opening tool on each of the designated spots to pry the keyboard apart from the palm rest.
- ⓘ You will hear a light "pop" sound each time you pry the keyboard.
- ⚠ Once the keyboard is loose, do not pull keyboard far (more than 3 inches) apart from the from the palm rest. There is a "bus" connector attached to the bottom.

Step 3



- Carefully disconnect the "bus" connector from the laptop. Press on it with your thumb/index finger and slide it right along the surface of the laptop.

To reassemble your device, follow these instructions in reverse order.