

Google Pixel 5a Headphone Jack Replacement

This repair guide was authored by the iFixit...

Written By: Clay Kim



INTRODUCTION

This repair guide was authored by the iFixit staff and hasn't been endorsed by Google. Learn more about our repair guides <u>here</u>.

Use this guide to remove or replace the headphone jack on your Google Pixel 5a.

For your safety, discharge the battery below 25% before disassembling your phone. This reduces the risk of a fire if the battery is accidentally damaged during the repair. If your battery is swollen, <u>take appropriate precautions</u>.

🖌 TOOLS:

🗘 PARTS:

ESD Safe Blunt Nose Tweezers (1) iOpener (1) Suction Handle (1) iFixit Opening Picks (Set of 6) (1) Spudger (1) Tweezers (1) T3 Torx Screwdriver (1)

Tesa 61395 Tape (1)

Step 1 — Precautionary notes



(i) Be sure to turn off your device before you begin the repair.

- ② You'll need to pry the screen up to remove it from the phone. Read the following notes carefully before proceeding.
- Take note of the two seams on the edge of the phone:
 - *Screen seam*: This seam separates the screen from the rest of the phone. **Do not pry at this seam.**
 - *Bezel seam*: This is where the plastic bezel designed to protect the screen meets the frame. It's held in place by plastic clips. **This is where you should pry.**

Step 2 — Heat the right edge of the screen



- <u>Apply a heated iOpener</u> to the right edge of the display for one minute to soften the adhesive.
- Depending on the strength of your device's adhesive, you may need to reapply the iOpener multiple times in order to weaken it enough.
- (i) A hair dryer, heat gun, or hot plate may also be used, but be careful not to overheat the phone—the display and internal battery are both susceptible to heat damage.



Step 3 — Bezel removal note

- (i) To remove the screen, you'll need to insert opening picks in between the black clips that secure the bezel to the midframe.
- Note the optimal points of entry before proceeding.

Step 4 — Create a gap between the bezel and midframe



- (i) If your display is badly cracked, covering it with a layer of clear packing tape may allow the suction cup to adhere. Alternatively, very strong tape may be used instead of the suction cup. If all else fails, you can superglue the suction cup to the broken screen.
- Place a suction cup as close to the right edge of the screen as possible.
- Lift the suction cup with a strong steady force until a small gap forms between the bezel and midframe.

Step 5 — Insert an opening pick



- (i) The bezel is connected to the midframe by a series of plastic clips which can be detached by inserting an opening pick at points all along the seam.
- Insert the tip of an opening pick into the *bezel seam* about 4-5 cm from the bottom of the phone.

Step 6



• Insert the tip of an opening pick into the *bezel seam* about 3-4 cm from the top of the phone.



- Insert the tip of an opening pick into the *bezel seam* at the top of the phone.
- If this step proves difficult, slide the pick along the top right corner of the phone until there is enough of a gap at the top for the opening pick.

Step 8



Insert the tip of an opening pick into the *bezel seam* at the bottom of the phone.
If this step proves difficult, slide the pick along bottom right corner of the phone until there is enough of a gap at the bottom for the opening pick.



• Insert the tip of an opening pick into the *bezel seam* on the left side of the phone, about 2 cm from the bottom of the phone.

Step 10



• Insert the tip of an opening pick into the *bezel seam* about 3-4 cm below the front-facing camera.



- Be sure to detach all the clips. Slice through any remaining adhesive with an opening pick.
- Open the device from the right side like a book.

Step 12



- Use a T3 Torx driver to remove the 4.6 mm-long screw securing the screen connector bracket.
- (i) Throughout this repair, <u>keep</u> <u>track of each screw</u> and make sure it goes back exactly where it came from.

Step 13 — Remove the connector bracket



• Use a pair of tweezers to remove the screen connector bracket.

Step 14 — Remove the screen



- Use the tip of a spudger to pry up and disconnect the screen flex cable.
- To re-attach <u>press connectors</u> like this one, carefully align and press down on one side until it clicks into place, then repeat on the other side. Do not press down on the middle. If the connector is misaligned, the pins can bend, causing permanent damage.



- Remove the screen from the phone.
- During reassembly:
 - If you replaced the screen, check the screen's frontfacing camera hole and remove any protective liners covering it.
 - *i* Remember to reinstall the screen connector bracket.
 - If you are using a custom-cut adhesive, follow <u>this guide</u> to correctly apply new screen adhesive.
 - If you are using Tesa tape to reattach the screen, <u>follow</u> <u>this guide</u>.
 - During the boot-up process after reassembly, the screen will go through a calibration sequence. Do not touch the screen during this process, as it could result in improper touch calibration and create touch issues.

Step 16 — Remove the screws



- Use a T3 Torx driver to remove six of the screws securing the midframe to the motherboard:
 - Four 4.6 mm screws
 - One 4.0 mm screw
 - One 2.0 mm screw
- Since a few of these screws have different lengths, keep track of each screw and be sure to reinstall them in their proper places.

Step 17 — Remove the black plastic cover



• Use the pointed end of a spudger to pry up on the black plastic cover at the bottom left of the phone.



- Slide the pointed end of the spudger left until the plastic cover is completely separated from the midframe.
- Remove the plastic cover from the midframe.

Step 19



• Use a pair of tweezers to slightly peel back the tape concealing the two screws securing the charging port bracket.

Step 20 — Remove the remaining screws



- Use a T3 Torx driver to remove the remaining four screws securing the midframe to the motherboard:
 - Three 4.6 mm screws
 - One 4.0 mm screw

Step 21



• Use a spudger or a pair of tweezers to peel back the tape securing the charging port bracket to the speaker assembly.

Take care not to puncture or bend the battery with your tool—a punctured or bent battery may leak dangerous chemicals or cause a fire.



• Use a **blunt** pair of tweezers, or your fingers, to carefully peel back the graphite sheet covering the battery.

A Be careful not to accidentally puncture or otherwise damage the battery when gripping the graphite sheet.

Step 23 — Detach the midframe



- Insert the pointed end of a spudger under the top right corner of the midframe.
- There is a black plastic clip at the top of the midframe that secures it to the top of the frame. To detach it, use the spudger to pull the midframe down and then pry up.

Step 24 — Remove the midframe



• Remove the midframe.

Step 25 — Replace the plastic bits



- There are two small plastic bits that help hold the midframe in place. Take care not to misplace them, as without the midframe to hold them in place, they are very easy to lose.
- Be sure to place these back into their respective corners **before** replacing the midframe when reassembling your device.

Step 26 — Disconnect the battery



• Use the flat end of a spudger to pry up on the battery connector to disconnect it.

Step 27 — Disconnect the headphone jack



• Use the pointed end of a spudger to pry up on the headphone jack connector to disconnect it.

Step 28 — Remove the headphone jack



- Use the flat end of a spudger to pry up on the headphone to pop it out of its socket.
- Remove the headphone jack.

To reassemble your device, follow these instructions in reverse order.

Take your e-waste to an <u>R2 or e-Stewards certified recycler</u>.

Repair didn't go as planned? Try some <u>basic troubleshooting</u>, or ask our <u>Google Pixel 5a</u> <u>Answers community</u> for help.

Compare your new replacement part to the original part—you may need to transfer remaining components or remove adhesive backings from the new part before you install it.