



# Dyson V8 Absolute Cyclone Replacement

Replacement of the Cyclone located in the main part of the device.

Written By: Jesse Coward



## INTRODUCTION

The Cyclone will need replacement if broken. There are multiple mechanisms in place to make access to the Cyclone easy.

## Step 1 — Cyclone



- ❗ First, make sure the device is unplugged and detach the wand from the main unit.
- Pull the bin release trigger.
- Some force is required to slowly pull the trigger up. lift the Cyclone until it stops.

## Step 2



- While holding the disposal tab, press on the red button within the device.
- Continue to lift up with red button held until cyclone is removed.
- ❗ Make sure the bottom of the bin opens when the Cyclone is removed

## Step 3



- Pull the pre-filter up by the knob.

To reassemble your device, follow these instructions in reverse order.