




Asus VivoBook X540SA-BPD0602V Battery Removal

In this guide you will learn how to safely remove the battery from the laptop case of your Asus VivoBook X540SA-BPD0602V.

Written By: Jessica Browne



INTRODUCTION

In this guide you will learn how to replace your Asus Vivobook X540SA-BPD0602V battery. Batteries should be replaced every couple of years because over time, they will fail to hold a charge. All power sources, including the battery, should be removed before completing any repairs or replacements within the device.

For your safety, discharge your battery below 25% before disassembling your device. This reduces the risk of a dangerous thermal event if the battery is accidentally damaged during the repair. If your battery is swollen, [take appropriate precautions](#).



TOOLS:

- [Magnetic Project Mat](#) (1)
- [iFixit Opening Tools](#) (1)
- [Phillips #1 Screwdriver](#) (1)



PARTS:

- [Asus A31-N1519 Replacement Battery](#) (1)

Step 1 — Keyboard



- Power down the laptop using the device's power button in top right corner of the keyboard. Ensure that the device's power cord is disconnected.

Step 2



- Flip the laptop over so the back panel is displayed.

Step 3



- Using a Phillips #1 screwdriver, remove the ten screws from the back panel.
- Remove the two battery screws (15.6 mm)
- Two top corner screws (12.5 mm)
- Six case screws (9.7mm)

Step 4




- Flip the laptop back over and open it, revealing the screen and keyboard.

Step 5




- Using the blue plastic opening tool, wedge and loosen the seal all the way around the edges. Carefully lift up the keyboard panel.
- ⚠ When lifting the keyboard panel, do not lift it all the way as the two connection ribbons to the motherboard must be disconnected.
- ℹ It is recommended to break the seal of the case starting at the upper corners closest to the display monitor .

Step 6



- Observe where the ribbons connect to the motherboard, there are two connections. Each connection has a black clamp. To remove the ribbon, lift the black clamp up to disconnect it.

Step 7 — Battery



- Very carefully, remove the batteries with the blue plastic iFixit opening tool. Focus removing the battery near the highlighted area.
- ⓘ The batteries should all be connected to one another and come out of the device as a single unit.
- ⚠ Be careful not to rip any of the black plastic covering the batteries. Exposed battery parts can lead to explosions. If the case is ripped, re-wrap them, or properly dispose of them. Do not reuse them.

To reassemble your device, follow these instructions in reverse order.

