iFIXIT

Lenovo G40-30 Keyboard Replacement

How to replace the Lenovo G40-30 keyboard.

Written By: Luke

| |

INTRODUCTION

Replacing the keyboard is a quick and easy task. Removing the keyboard only took three tools: A JIS #1 screwdriver, plastic opening tool, and tweezers. Before you start make sure you remove the battery and unplug the device.

🔧 TOOLS:

- iFixit Opening Tools (1)
- Tweezers (1)
- JIS #1 (1)

Step 1 — Battery

- At the top of the laptop you will see two switches, like in image one and two.

- Pull the switches outwards with your thumb, towards the unlocked lock.

Step 2

- Once both switches are pulled, the battery should pop out.

Step 3

- Now you are ready to insert your new battery.

Step 4 — Keyboard

- Use a JIS #1 screwdriver to remove the two 7 mm screws.

This document was generated on 2020-11-28 06:40:13 AM (MST).

Step 5

- Remove the back panel by sliding it away from the battery.

Step 6

- Use a JIS #1 screwdriver to remove the three 7 mm screws.

This document was generated on 2020-11-28 06:40:13 AM (MST).

Step 7

- Wedge the plastic opening tool in-between the keyboard and the base of the laptop.

- Continue using the plastic opening tool to pry around the edge until the keyboard is completely freed form the frame.

- The keyboard should only be connected by a ribbon on the underside of the keyboard.

- (i) It is recommended that you slowly pull the keyboard out as your move around the edge. As in picture 2.

- ⚠ Be careful not to pull the keyboard too far away from the face as it will damage the data ribbon.

This document was generated on 2020-11-28 06:40:13 AM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 6 of 7

Step 8

- Use the tweezers to lift the black hinge on the ribbon connector.

- Then pull the ribbon from the connector and remove the keyboard from the laptop.

Step 9

- Now your keyboard is free to be replaced!

To reassemble your device, follow these instructions in reverse order.