

Toshiba Satellite C55-A5310 Battery Replacement

How to replace a Toshiba Satellite C55-A5310 battery.

Written By: Kari Rodgers



Step 1 — Battery







- Push the left tab with your left hand.
- Then push the right tab with your right hand.
- While your right hand is still pushing, remove the battery with your left hand.

To reassemble your device, follow these instructions in reverse order.