

Dell Inspiron 15-7547 Bottom Cover Replacement

Replace your cover if it is damaged, or remove to get to the parts inside.

Written By: Claro



This document was generated on 2020-11-28 06:54:20 AM (MST).

INTRODUCTION

This guide shows how to unscrew and remove the bottom cover of your Dell Inspiron 15-7547, allowing access to the underside of the computer where all the important components are.

TOOLS:

• Spudger (1)

۶

• Phillips #0 Screwdriver (1)

This document was generated on 2020-11-28 06:54:20 AM (MST).

Step 1 — Bottom Cover



- (i) Before you begin, be sure to turn off your laptop and unplug it from the outlet.
 - Close the display and flip the laptop on its back.
 - Loosen the ten 5.0 mm-long Phillips #0 screws.
 - The four screws marked with orange will remain captive to the cover.

Step 2



- Use a spudger to pry up and loosen the back cover.
- Remove the back cover.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 06:54:20 AM (MST).