



# DOSS SoundBox Grille Removal

Here you will learn how to remove the protective speaker grille on your DOSS SoundBox.

Written By: Jimmy Baertlein



---

## INTRODUCTION

This guide will be helpful for removing the protective speaker grill on your DOSS SoundBox. Removing this protective speaker grill will help you get to the speakers if they or the grill is damaged and needs repaired. The process should take around 5 minutes to complete, and doesn't need any special skills. Be aware of the possibility of scratching the soundbox when removing grill.

---



### TOOLS:

- [iFixit Opening Tool](#) (1)
-

## Step 1 — DOSS SoundBox Grille Removal



- Use a small plastic opening tool to gently lift the side of the grille.
- Gently slide the tool to the front of the speaker.
- Repeat the process on the bottom of the grille.
- Gently pull the grille off of the speaker enclosure.

 Pry with caution, for the grille is fragile.

To reassemble your device, follow these instructions in reverse order.