



ZTE Tempo X Volume Buttons Replacement

This guide will show you how to replace your volume buttons on your ZTE Tempo X.

Written By: Conager Robb



INTRODUCTION

Use this guide to replace the volume buttons on your ZTE Tempo X.

TOOLS:

- [Tweezers](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Back Cover



- Remove back cover using the divot provided.

Step 2 — Battery



- Find the divot near the bottom of the battery and remove the battery from the device.

Step 3 — Volume Buttons



- Using a Phillips #00 screwdriver, remove the sixteen 3 mm screws holding the back panel in place.
- Remove the back panel.

Step 4



- To remove the volume keys, pull them away from the phone. The keys will slide out from their set position.

 Be aware of the edges of the phone when removing the keys.

To reassemble your device, follow these instructions in reverse order.