



WEN 18 Gauge 2-Inch Air Brad Nailer Male Air Compressor Adapter Gasket Replacement

This guide will aid in replacing the WEN 18 Gauge 2-Inch Air Brad Nailer Male Air Compressor Adapter Gasket.

Written By: Ousman Jammeh



This document was generated on 2020-11-28 07:03:04 AM (MST).

INTRODUCTION

If you need to replace a Brad Nailer Male Air Compressor Adapter Gasket, follow the steps outlined in this guide. For this guide, you will need a crescent wrench and flathead screwdriver. The steps outlined are relatively easy to follow.

TOOLS:

- [Metal Spudger](#) (1)
 - [Adjustable Wrench](#) (1)
-

Step 1 — Male Air Compressor Adapter Gasket



- Using a crescent wrench, loosen the yellow nut located between the grip and the male air compressor adapter.

Step 2



- Remove the yellow component.

Step 3



- Use a spudger to pry the gasket from the base of the threads.

To reassemble your device, follow these instructions in reverse order.