

Keurig B70 Platinum K-Cup Portion Pack Holder Replacement

Replace the portion pack holder on your Keurig B70 Platinum if you encounter any problems with it.

Written By: Thu Hoang



This document was generated on 2020-11-28 07:04:33 AM (MST).

INTRODUCTION

K-Cup pack holder is stuck?

This guide will show you how to remove and replace the K-Cup Portion Pack Holder for the Keurig B70 Platinum if you're experiencing any problems with the pack holder. Before continuing with the guide, you're going to need a Phillips #2 screwdriver.



TOOLS:

Phillips #2 Screwdriver (1)

Step 1 — K-Cup Portion Pack Holder





- Turn off and unplug the Keurig before starting.
- Open the lid and remove the two 11.0 mm screws located below the K-Cup holder.

Step 2



- Pull the black plastic guard of the K-Cup housing away from the Keurig.
- i Depending on the angle, the guard can actually fall out instead. Be ready to catch it!

Step 3







- Push the black button at the bottom of the lid to remove the K-cup holder assembly.
- From the top, lift the assembly out of the Keurig.

Step 4





- Grab the top and the bottom of the holder assembly and pull it apart.
- ↑ Be careful when pulling the assembly. There is a sharp needle!
- (i) This step requires a little force.

To reassemble your device, follow these instructions in reverse order.