




Vulcan Venture II VNB14002IE I/O Board Replacement

Written By: Parish Brandt



TOOLS:


JIS #00 Screwdriver (1)

Step 1 — Back Panel




- Use a J00 screwdriver to unscrew the 10 back-plate screws.

Step 2





- Gently separate the back panel from the laptop.

Step 3 — I/O Board



- Locate the IO board on the back panel.

Step 4




- Locate the ribbon connector on the IO board, and lift the black bar closest the the ribbon.
- Pull the ribbon cable away from the connector, releasing it.

Step 5



- Locate the screws on the IO panel, and use the J00+ bit to unscrew them.

Step 6



To reassemble your device, follow these instructions in reverse order.