



Kenmore 78423 Vacuum hose Replacement

This guide will show you how to detach the vacuum hose from the main body of your Kenmore 78423.

Written By: Christopher Bradley



INTRODUCTION

Learn how to detach the vacuum hose from your Kenmore 78423.

Step 1 — Vacuum hose



- Grasp and press buttons on both sides of the base of the hose.
- While still pressing the buttons, rotate the base a quarter-turn clockwise.
- Lift the hose away from the machine

To reassemble your device, follow these instructions in reverse order.