



Ordro HDV-D395 Battery Replacement

Guide for removing battery from Ordro HDV-D395 camcorder.

Written By: Nathan McIntyre



INTRODUCTION

It is important to remove this power source if the device is not working, as well as if further dismantling of the product is needed.

Step 1 — Battery



- Pull the slider labeled open, on the bottom right, to unlock the battery.

Step 2



- Pull battery out of slot.

To reassemble your device, follow these instructions in reverse order.