



# Nikon Coolpix 775 Battery Replacement

How to remove and replace the battery for the Nikon Coolpix 775.

Written By: Suketu Patel



## INTRODUCTION

Trying to figure out where the battery is located in the Nikon Coolpix 775? Follow this step-by-step guide to learn how you can remove the battery.

## Step 1 — Battery



- Flip the camera, so the bottom is facing up.

## Step 2



- Slide the gray latch to the open "pac-man" symbol.

## Step 3



- Flip up the cover and remove the battery inside the slot.

To reassemble your device, follow these instructions in reverse order.