



# Anker Soundcore A3102 Partial Teardown

Opening my dead Soundcore just to see what's inside + PDF of parts inside the Soundcore from the FCC.

Written By: Daniel Bui







## TOOLS:

- [Metal Spudger](#) (1)
  - [Phillips #1 Screwdriver](#) (1)
  - [64 Bit Driver Kit](#) (1)
-



## Step 1 — Anker Soundcore A3102 Partial Teardown



- Insert metal spudger between metal grill and rubber.
- Pry the grill off.
- ⓘ Grill is held on with adhesive.

## Step 2



- Unscrew 8 screws using a size 1 phillips head screwdriver.
- ⓘ Screws may be difficult to remove.
- ⓘ 4 screws are around each audio driver, totaling 8.



## Step 3



- Using the same prying method in Step 1, remove the plastic holder for the two speakers.
- Carefully lift up and away from the rest of the device.

⚠ There are speaker wires that permanently connect the audio drives to the board.