

Asus K52F-BBR5 Battery Replacement

Written By: Melissa Cruz



INTRODUCTION

Once your battery's life shortens, this guide can help you replace it.

Step 1 — Battery



- Place the laptop face down and have the battery facing away from you.
- Make sure that the button to the right of the battery is unlocked by sliding it to the right. (It becomes red when unlocked.)

Step 2





- While holding the the left button, slide the battery with your other hand.
- Right button should be red (shown in picture.)

To reassemble your device, follow these instructions in reverse order.