



ASUS K53E-BBR1 Battery Replacement

This guide will show you how to replace the battery of the ASUS K53E-BBR1.

Written By: Matthew Merlo



INTRODUCTION

If you have found that your battery needs to be replaced, this guide will show you how to take the old battery out. This guide is very simple and doesn't require any tools.

Step 1 — Battery



- Flip the laptop over so you can see the battery.

Step 2



- Slide the lock on the right side of the battery to the right. If done correctly the slider will stay in place and there will be a red indicator.

Step 3



- Slide the other sliding lock on the left side of the battery to the left, and with your other hand slide the battery out from the laptop.

To reassemble your device, follow these instructions in reverse order.