

# Lenovo Tab 4 TB-8504F Rear Camera Replacement

Learn how to replace the Lenovo Tab 4 8 rear camera.

Written By: Ivan Chavez





## **TOOLS:**

- Phillips #000 Screwdriver (1)
- Spudger (1)
- iFixit Opening Picks set of 6 (1)
- Tweezers (1)

#### Step 1 — Battery







- Start at the microSD slot.
- Use the opening pick to slide underneath the back cover of the tablet.
- Slide the opening pick around the tablet until the back cover is off.

#### Step 2







- Remove the 8 screws with a Phillips #000 screwdriver [bit].
  - There is a screw under the blue "s" sticker.
- Remove tape holding plate down.
- Use precision tweezers or your fingers to remove plate.

#### Step 3





- Remove yellow tape.
- Use a spudger or plastic opening tool to remove the battery's ribbon cable from the motherboard.

### Step 4







- Gently pull on the two stretch release adhesive strips. Do not pull up, pull away from battery.
- Once the tabs are off, lift the battery up from the frame.
- ♠ Do not bend or puncture the battery.

## Step 5 — Rear Camera





- Use a spudger to lift the rear camera press-fit connector up and free.
- Use tweezers to lift the rear camera out of the frame.

To reassemble your device, follow these instructions in reverse order.