



Lexmark Intuition S505 Ink Cartridges Replacement

This guide will provide a step-by-step procedure for replacing the ink cartridges.

Written By: Omar



INTRODUCTION

Ink cartridges allow the printer to print using the ink in the cartridges. The colors included are black, yellow, blue and pink.

Step 1 — Ink Cartridges



- Lift the scanning unit, exposing the print head.

Step 2



- Locate the frame around the ink cartridges. Press the button located at the front of the cartridge frame.

Step 3



- Lift the frame to expose the ink cartridges.

Step 4



- Push the button located above the designated ink cartridge until it pops out.

Step 5



- Pull the cartridge out, and place the new ink cartridge back into the slot. Push until you hear a click.

Step 6



- Close the scanner unit.

Once your ink cartridges are in place, your printer should now print high-quality documents.