



LG Net10 SIM Card Replacement

How to replace the SIM card in an LG Net10.

Written By: Gina



INTRODUCTION

Use this guide to remove or replace the SIM card in your LG Net10. This may help with difficulties making or sending calls, texts, emails, or otherwise using the internet.

This guide requires no tools or advanced knowledge to follow.

Step 1 — SIM Card



- Remove the battery back cover by applying pressure downwards along the groove.
- ⓘ The LG logo should be upright.

Step 2



- Remove the battery from the compartment to reveal the SIM card.

Step 3



- Remove the SIM card by pushing down on the top and slide it out from under the metal band upwards.

To reassemble your device, follow these instructions in reverse order.