



Dangle Earrings Jump Ring Replacement

This guide will teach you to easily repair and replace a small jump ring on a dangle earring that may have broken.

Written By: Angelika Dela Torre



INTRODUCTION

This guide will teach you to easily repair and replace a small metal jump ring on a dangle earring that may have broken. This guide is applicable to any dangle earring with a stud or hoop and can be easily done at home within 30 minutes. To ensure a successful repair carefully follow the step provided with the listed parts.



TOOLS:

- [Cutting Plier](#) (1)
 - [Chain Nose Pliers](#) (1)
-

Step 1 — Jump Ring



- Locate where the earring stud/hook has detached.
- Look at the two pieces of the dangle earrings for a small loop or jump ring on both pieces.

Step 2



- Using a chain nose plier, carefully grip the jump ring by its side.
- Use a cutting plier to cut a small opening in the loop.

Step 3



- With both pliers use the cutting plier to gently grip the side of the small jump ring.
- Using the small nose chain pliers pull back on the small jump ring to create an opening.

Step 4



- With the small chain nose pliers grip the jump ring.
- Insert the stud/hook portion of the earring into the jump ring.

Step 5



- Use the jump ring to reattach the the stud.
- With the small chain nose pliers grip the jump ring.
- Insert the main portion of the earring into the jump ring with the stud/hoop.

Step 6



- Use both pliers to close the loop.
- Firmly grip the edge of the loop using a pair of cutting pliers.
- With a pair of small chain grip pliers gently push the end of the jump ring forward to close the loop.

Step 7



- Gently tug on either side of the earring to ensure the loop is closed securely.
- ⓘ If this test fails, refer back to step 6.

To reassemble your device, follow these instructions in reverse order.