

MacBook Pro 15" Unibody 2.53 GHz Mid 2009 Hard Drive Replacement

Written By: Walter Galan



INTRODUCTION

This guide is an internal private guide used as prereq.



TOOLS:

• Phillips #00 Screwdriver (1)

Step 1 — Hard Drive





- Remove two Phillips screws securing the hard drive bracket to the upper case.
- (i) These screws are captive to the hard drive bracket.
- Lift the the retaining bracket out of the upper case.

Step 2



 Lift the hard drive by its pull tab and pull it out of the chassis, minding the cable attaching it to the computer.

Step 3





Remove the hard drive cable by pulling its connector straight away from the hard drive.

To reassemble your device, follow these instructions in reverse order.