

How to clean Game Boy Advance buttons

Written By: Adam



INTRODUCTION

Use this repair guide to clean sticky buttons.



TOOLS:

- Cloth (1)
- tooth brush (1)

Step 1 — How to clean Game Boy Advance buttons





• Use a slightly damp toothbrush to scrape in between the desired sticky buttons. You can also use a bit of isopropyl alcohol.

Step 2



 Dry with a cloth after the sticky residue is removed.