



# Samsung SCH-U340 Battery Replacement

This guide shows how to replace the battery in...

Written By: Mitchell Walker



## INTRODUCTION

This guide shows how to replace the battery in a Samsung SCH U340 cell phone. This is important because it is a prerequisite for all other repair guides.

## Step 1 — Battery



- Turn the cell phone so that the back side is facing you.
- Press the upper indent and slide the back cover down.

## Step 2



- Pull the battery up from indent at the bottom and slide it out.

