

Disassembling Xbox 360 E Bottom Panel

Remove the bottom panel of the Xbox 360 E.

Written By: Jennifer



INTRODUCTION

This guide is a prerequisite for another replacement guide.



F TOOLS:

• Spudger (1)

Step 1 — Bottom Panel



- Push the spudger into the crevice between the right grated face and the top body of the Xbox. It's easier to begin away from the vent.
- Pull up on the spudger like a lever, keeping it pressed firmly into the crevice.

Step 2





Slide the spudger along the crevice to separate the grated face and the top body.

Step 3







- Wiggle the spudger in the crevice as you slide the spudger to loosen the bottom plate.
- Slide the spudger along the crevice, going completely about the perimeter of the bottom panel.
- Pull the bottom panel off.

To reassemble your device, follow these instructions in reverse order.