



Canon EOS Rebel T4i Battery Replacement

This guide will help the user replace the battery of the device.

Written By: Nimisha Patel



INTRODUCTION

This guide will inform the user what to do if the battery needs to be replaced.

Step 1 — Battery



- Locate the battery cover at the bottom of the camera.
- Pull down on the black tab to open the cover.

Step 2



- Push the grey tab on the right side of the battery.
- Remove the battery from the slot.

To reassemble your device, follow these instructions in reverse order.