



iPhone 6 Plus Battery Connector Replacement

Prereq to disconnect the battery.

Written By: Jeff Suovanen



INTRODUCTION

Prereq-only guide to disconnect the battery.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #000 Screwdriver](#) (1)
-

Step 1 — Battery Connector



- Remove the following screws from the battery connector bracket:
 - One 2.3 mm Phillips #00 screw
 - One 3.1 mm Phillips #00 screw

Step 2



- Remove the metal battery connector bracket from the iPhone.

Step 3



- Use a plastic opening tool to gently pry the battery connector up from its socket on the logic board.
- ⚠ Take care to **only** pry up on the battery connector, and not the socket on the logic board. If you pry up on the logic board socket, you may break the connector entirely.

To reassemble your device, follow these instructions in reverse order.