



How to Level the DJI Phantom 2 Vision+ Camera Gimbal

This guide shows how to adjust the horizon level on the roll axis of the camera gimbal.

Written By: David Hoyt



INTRODUCTION

This guide shows how to adjust the horizon level on the roll axis of the camera gimbal.

Note: The guidemaker broke the ZIF tab on the board's ribbon cable, be careful, and refer to this guide to [disconnect ZIF connectors](#).

[video: <https://www.youtube.com/watch?v=5iTz3Dd2Ecs>]

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

To reassemble your device, follow these instructions in reverse order.