

iRobot Roomba 655 Pet Series Side Brush and Back Panel Removal

How to remove the side brush and back panel of your Roomba

Written By: Matt Davis



This document was generated on 2020-11-16 11:14:07 PM (MST).

INTRODUCTION

You will be removing the yellow side brush and the back panel of your Roomba in order to gain access to other components of your device.



TOOLS:

- Phillips #2 Screwdriver (1)
- Phillips #1 Screwdriver (1)

Step 1 — Removing the Side Brush





- Flip the device over onto its back.
- Find the side brush, and unscrew the single screw that connects to brush motor by using the Phillips head #2 screwdriver.
- (i) This screw doesn't completely come out of the yellow side brush.

Step 2 — Removing the Back Panel





- Using a Phillips #1 screwdriver, remove the four screws on the back panel.
- Once the screws are loose gently pry the back plate away from the body by using the spudger tool.
- (i) The screws don't completely come out of the panel, but it will still come apart once unscrewed.

To reassemble your device, follow these instructions in reverse order.