

iRobot Roomba 655 Pet Series Front Face Plate Replacement

How to remove that shiny silver front face plate on your Roomba

Written By: Rhett



This document was generated on 2020-11-16 11:14:48 PM (MST).

INTRODUCTION

Removing this silver casing will give you access to the screws on the inner face plate beneath. Removing this is your first step.

Step 1 — Front Face Plate





- Remove the dust bin by pushing on the button for the dust bin removal
- Pull the dust bin out

Step 2





- Pull up on the silver handle to release the top protectant plastic
- Remove the top plastic carefully

To reassemble your device, follow these instructions in reverse order.