

 **TOOLS:**

- [3/32" Allen Wrench](#) (1)

Step 1 — Separate Body From Grip Frame



- Remove the front and rear 1" screws on the gun's grip frame using a 3/32" Allen Wrench.

Step 2



- Remove the 12 mm screw on the top of the grip frame using a 3/32" Allen wrench.

Step 3



- Separate the gun's body from the frame by gently pulling them in opposite directions.

Step 4



- Remove the 1-1/4" screw that's attached to the blue tube above the front grip using a 3/32" Allen Wrench.

To reassemble your device, follow these instructions in reverse order.