



Nokia 3395 Back Case Replacement

Nokia 3395 is a classic mobile phone that may r...

Written By: bushing



INTRODUCTION

Nokia 3395 is a classic mobile phone that may require back case removal for various reasons, such as troubleshooting, part replacement, or customization. In this guide, we will walk you through the process of safely opening the back case, providing access to the phone's internal components.

What Is Accomplished by This Guide:

This guide empowers you to:

- Access and inspect the internal components of the Nokia 3395.
- Perform maintenance tasks, such as replacing a damaged battery or troubleshooting issues.
- Understand the role of the back case in protecting the phone's internals and how to safely remove it.

About the Part Being Replaced:

The back case, also known as the back cover or rear housing, serves a crucial role in safeguarding the Nokia 3395's internal components. It provides protection against physical damage, dust, and moisture. When removed, it grants access to the battery, circuitry, and other integral parts of the device.

Device's Symptoms and Relevant Troubleshooting:

If you're experiencing specific issues with your Nokia 3395, such as power problems, battery issues, or signal reception concerns, we recommend referring to our [troubleshooting page](#) for detailed guidance on diagnosing and addressing these symptoms.

Important Tips and Warnings:

- **Swollen Batteries:** Be cautious when dealing with swollen or damaged batteries. Avoid puncturing or mishandling them, as they may leak harmful chemicals. Safely dispose of damaged batteries following local regulations.
- **Shattered Glass Displays:** If your Nokia 3395 has a shattered display, exercise extreme care when handling broken glass.
- **Damaged Waterproofing:** Removing the back case may compromise the phone's waterproofing features. Take extra precautions to keep the phone away from water and moisture after reassembly.
- **Removing Power:** Ensure the phone is powered off before beginning the disassembly process to reduce the risk of electrical hazards.

By following this guide and taking heed of these tips and warnings, you can confidently proceed with disassembling the Nokia 3395 back case, empowering yourself to address various device-related issues effectively.

Step 1 — Back Case



- Turn the phone off.
- Hold the phone, and gently press the white button located at the bottom of the phone.
- While pressing the button, slide the back plate upwards, opening the plate.

To reassemble your device, follow these instructions in reverse order.