

# Nokia 2128i Power Unit Replacement

This guide will show you how to replace your phone's power unit.

Written By: Andres Echeverria





- T6 Torx Screwdriver (1)
- iFixit Opening Tools (1)

## Step 1 — Battery







- Be sure cell phone is off before you begin to disassemble the phone.
- Press the button on the bottom of the back of the cell phone.
- Slide rear panel down and remove it.

# Step 2







Using your fingernail, pry the back of the battery upwards and pull out.

#### Step 3 — Faceplate







- Insert the plastic opening tool under the faceplate.
- Separate the faceplate from main body by twisting the prying tool with some force.
- The faceplate is held by three plastic fasteners, so pry evenly on both sides of phone.

#### Step 4 — Keypad








With the faceplate removed, simply peel off rubber key pad and remove.

## **Step 5** — **Motherboard Assembly**







- Locate and remove the six screws on the front of the phone using a T6 Torx.
  - All 6 screws are 6.9mm long.

# Step 6







After removing screws, lift the motherboard assembly straight off the cell phone body.

#### Step 7 — Power Button







• With the motherboard and LCD unit removed, gently pull the power button out of its housing.

## Step 8 — Power Unit







- Flip phone over and find the sticker that holds the metallic plating together with the phone's case.
- Pry off the portion of the sticker that is attached to the phone's case. Do not worry about removing the sticker from the metallic plate.

## Step 9









- Locate the small hook that holds the metallic plate and phone case together on the front side of the phone
- Place your thumbs on the backside of the metallic plate.
- Stretch phone casing outward to detach hook from metallic plating. Simultaneously push metallic plate outward to remove.

## Step 10







Pry out the power unit once the metallic plate has been removed.

# Step 11



 Be sure to place the power unit back into the phone's case with the gold hardware pointing upward.

To reassemble your device, follow these instructions in reverse order.