



HTC One M8 SIM Card Replacement

Replace the SIM card.

Written By: Geoff Wacker



INTRODUCTION

Use this guide to replace the SIM card on your HTC One M8.



TOOLS:

- [SIM Card Eject Tool](#) (1)



PARTS:

- [HTC One \(M8\) SIM Card Tray](#) (1)

Step 1 — SIM Card



- Insert a SIM card eject tool or a paperclip into the small hole in the SIM card tray, located on the upper left hand side of the phone.
- Press to eject the tray.
- ⓘ This may require a significant amount of force.

Step 2



- Remove the SIM card tray assembly from the HTC One M8.
- ⚠ When reinserting the SIM card, ensure that it is in the proper orientation relative to the tray.

To reassemble your device, follow these instructions in reverse order.