

Panasonic ER-GN30-K Battery Replacement

Is your Panasonic ER-GN30-K battery dead? Here...

Written By: Alejandro Garabatos



INTRODUCTION

Is your Panasonic ER-GN30-K battery dead? Here is a quick guide on how to swap it out for a fresh one.

🌣 PARTS:

AA Battery (1)

Step 1 — Battery



• Remove the back battery cap from the device by twisting it to the unlock position and pulling.

Step 2



- Remove the dead or corroded battery by pulling the uncovered end out and sliding the rest of the battery out.
- ▲ If the battery is corroded, do not touch it with your bare hands. Residual battery acid can burn your skin,

To reassemble your device, follow these instructions in reverse order.