




# Samsung Galaxy Tab 4 7.0 Camera Replacement

The front and rear facing cameras are both...

Written By: Aubrey Goodwin



## INTRODUCTION

The front and rear facing cameras are both right next to each other and require the same tools and process for removal.

### TOOLS:

[Phillips #000 Screwdriver](#) (1)

[iFixit Opening Tool](#) (1)


[Tweezers](#) (1)

### PARTS:

[Galaxy Tab 4 7.0 Rear Camera](#) (1)

[Galaxy Tab 4 7.0 Front Camera](#) (1)

## Step 1 — Back Panel






- Starting at any corner, insert the pry tool between the chrome screen frame and black phone housing.
- Slide the pry tool around the tablet while applying force to pry the screen away from the phone housing.

## Step 2



- Carefully separate the rear housing from the front panel assembly.


## Step 3 — Motherboard



- Using the bent [tweezers](#), carefully pull the flat cables away from the connectors.


⚠ Do not bend the flat cables at the tips as they may become permanently deformed.

## Step 4




- Using the plastic opening tool, gently pry the chip connections away from the motherboard.

## Step 5



- Use the Phillips 000 screwdriver to remove the remaining five 1.2 mm screws.


## Step 6



**⚠ Use extreme care while removing the motherboard to avoid damaging the component.**

- Remove the motherboard by rotating it away from the rest of the phone as shown in the first photo.

## Step 7 — Camera



- With the [tweezers](#) grab the base of the wire harness and slide it outward in the direction shown.
  - ⓘ This can be done for either camera on the tablet.

To reassemble your device, follow these instructions in reverse order.