

HP Pavilion zd8000 RAM Replacement

Written By: Allie Menard



INTRODUCTION

Removing the RAM from this device is straightforward and requires little disassembly.



TOOLS:

• Phillips #1 Screwdriver (1)



PARTS:

- PC2-5300 1 GB RAM Chip (1)
- PC2-5300 512 MB RAM Chip (1)

Step 1 — Battery



 Slide the battery release latch towards you.

Step 2





Pull up on the battery to remove it.

Step 3 — RAM





Loosen the Phillips screw labeled 'ram' and lift the cover.

Step 4





- Locate the green RAM card and find the metal tabs securing the card.
- Push outwards on the two tabs to release the card.

Step 5



 Carefully slide the card out at an upward angle away from the slot.

To reassemble your device, follow these instructions in reverse order.