

Dell Inspiron 8600 Cooling Fan Replacement

This guide shows you how to remove the cooling...

Written By: John Nesthus



INTRODUCTION

This guide shows you how to remove the cooling fan in your Dell Inspiration 8600. The cooling fan regulates the computer's temperature. First you must remove the hinge cover and keyboard lower case to finally have access to the cooling fan.



Phillips #1 Screwdriver (1)

Step 1 — Battery



- Remove the battery from the bottom left of the laptop as shown.
- A Remove the battery before operating on the computer to avoid electrocution.

Step 2 — Cooling Fan







- Remove both screws from the fan using a Philips head screwdriver.
- Slide off the cooling fan.

To reassemble your device, follow these instructions in reverse order.