



# Shop-Vac MC150A Power Unit Assembly Replacement

This guide will show you how to remove and replace the power unit assembly for the MC150A Shop-Vac.

Written By: Ngunlian



---

## INTRODUCTION

This guide will show you how to remove and replace the power unit assembly for the MC150A Shop-Vac.

---

### TOOLS:

- [3.5mm Hex Key](#) (1)
-

## Step 1 — Unlatch the power unit assembly



- ⓘ Before you begin, make sure to switch off the device and unplug it from the outlet.
- Unlatch the two side clips securing the power unit assembly to the tank.
- Remove the power unit assembly from the tank assembly.

## Step 2 — Remove the top cover



- Use a 3.5 mm hex key to remove the three screws securing the top cover.
- Remove the top cover.

### Step 3



- Use a 3.5 mm hex key to remove the four screws securing the power unit assembly.

### Step 4



- Separate the power unit assembly from the cover.

To reassemble your device, follow these instructions in reverse order.