



# Nexus 5X Rear Panel Replacement

This guide shows how to replace the rear panel of the Nexus 5X.

Written By: Dominik Schnabelrauch



## INTRODUCTION

Use this guide to remove the rear panel of your Nexus 5X.



### TOOLS:

- [SIM Card Eject Tool](#) (1)
- [iFixit Opening Picks set of 6](#) (1)



### PARTS:

- [Nexus 5X Rear Panel](#) (1)

## Step 1 — SIM Card Tray



- Insert a SIM card ejection tool into the hole on the SIM card tray, located on the left edge of the phone.
- Press in to eject the SIM card tray.
- Remove the SIM card tray.

## Step 2 — Rear Panel



- Place an opening pick in the opening of the SIM card tray slot and twist it sideways to release the first plastic clip that holds the rear panel in its place.
- Slide the opening pick around the top edge of the phone to release the plastic clips that secure the rear panel.

### Step 3



- Continue to slide the opening pick around all sides of the phone to release all clips that secure the rear panel.

### Step 4



- Tilt the opening pick to lift the rear panel a little bit.
- There are two more plastic clips next to the fingerprint sensor. Release them by gently pulling the rear panel.
- Remove the rear panel.

To reassemble your device, follow these instructions in reverse order.

Repair didn't go as planned? Check out our [Nexus 5X Answers community](#) for troubleshooting help.