

KitchenAid KHM512ER Beater Rings Replacement

Replacing the beater rings on the KitchenAid KHM512ER.

Written By: Brad Daniels



This document was generated on 2020-11-28 05:02:36 AM (MST).

INTRODUCTION

Are your beaters not staying in? You may need to replace the beater rings.



TOOLS:

- iFixit Opening Tools (1)
- Phillips #2 Screwdriver (1)
- Tweezers (1)


Step 1 — Beater Rings





- Insert the back of a plastic opening tool into one of the beater holes
- Apply force to pull the circular plastic part off.
- If necessary, use the other side of the plastic opening tool to pry the circular plastic part off.

Step 2





KitchenAid KHM512ER Beater Rings Rep...



- Use a Phillips #2 screwdriver to remove the two 20mm screws holding the bottom plastic piece in place.
- Remove the bottom plastic piece using a plastic opening tool.


Step 3






- Using a Phillips 2 screwdriver, remove the three 20.0mm screws holding the motor assembly in place.
- Use your hands to remove the motor assembly.

Step 4






Firmly grip the motor in your hand. Using pliers, pull the connectors off the motors.

↑ Some force may be required. Be careful not to cut yourself on any electrical components.

Step 5





- Lie the motor down flat on a table.
- Using a pair of tweezers, remove the ring from the plastic knob.

To reassemble your device, follow these instructions in reverse order.