



Power Button Dead?

The power button becomes non-functional on my AL1912 Here is a quick fix to try if you have similar issues. May work on other similar Acer products as well (not sure though).

Written By: tcagle53



Step 1 — Power Button Dead?



- The power button becomes non-functional on my AL1912 Here is a quick fix to try if you have similar issues. May work on other similar Acer products as well (not sure though).

Step 2



- I attribute these episodes to power dropouts or spikes or sunspots (not sure in other words). I fix it about once a year like this Press and Hold these three buttons on the lower control panel: > (right arrow) + Menu + Power When the power comes on you are done. These are the three buttons I've colored red in the photo.