

Acer Chromebook CB3-111-C8UB Key Replacement

This guide is for replacing single keys on the keyboard if they have fallen off or are faulty.

Written By: Travis Vo



This document was generated on 2020-11-20 04:23:35 PM (MST).

INTRODUCTION

This guide will show you how to remove a key from the keyboard. This is helpful if something gets lodged underneath it or if the key is cracked and you wish to replace it.

TOOLS:

• iFixit Opening Tools (1)

This document was generated on 2020-11-20 04:23:35 PM (MST).

Step 1 — Key



- Slide the plastic opening tool under the key you wish to remove until it is up against the bottom part of the key.
- Then, lever the plastic opening tool. It should catch the key.
- Finally, keep levering the key until it pops out.
- (i) We do this to avoid depressing the key. It becomes much harder to catch the lip with the key pushed down.

To put the key back in place, simply push down on it until you hear the clips snap into place.

This document was generated on 2020-11-20 04:23:35 PM (MST).