

Acer Aspire TimelineX 4830T-6682 Back Panel Replacement

Written By: Rachel Wagner





- Phillips #0 Screwdriver (1)
- iFixit Opening Tools (1)

Step 1 — Lower Back Panel







- Remove the single screw with a Phillips #0 screwdriver.
- Use a plastic opening tool on the upper part of the panel to remove it and access the RAM.
- (i) The other way to remove the panel is by sliding it away from the laptop. The difficulty of sliding it depends on the condition of your laptop.

To reassemble your device, follow these instructions in reverse order.