HP Pavilion dv5000 Keyboard Replacement

This guide will show you how to remove the...

Written By: Alex Kwok

INTRODUCTION

This guide will show you how to remove the keyboard, in case you need to replace it.

🔧 **TOOLS:**

Phillips #00 Screwdriver (1)

Step 1 — Battery

⚠️ Turn off the computer, and unplug it from all external power sources.

● Lay the computer face-down on a flat surface. Orient the computer to match the image.

● Locate the battery release switch, as indicated in the image by the red rectangle. Slide the switch from right to left, and remove the battery.

Step 2 — Keyboard

- Remove the two 11.0mm screws at the corners on either side of the battery compartment.

- Remove the three 6.0mm screws.

- Remove the two 5.0mm screws.

- Remove the 6.0mm screw in the middle of the battery compartment.

Step 3

- Turn the computer over and open the screen. This provides access to the screen hinges.

- The keyboard switch cover is attached to the computer with a series of snaps. With a flathead screwdriver, pry up the switch cover until it pops free.

Step 4

- Be careful not to bend the keyboard switch cover too far when removing it.

Step 5

- Next, remove the keyboard. Push on the keyboard frame above the function keys and slide the keyboard toward the screen.

Step 6

- Carefully lift the trackpad-side edge of the keyboard to reveal the LED and keyboard cable connectors.

- Detach the cable connectors from the computer by gripping each cable connector close to the computer contact point and pulling up gently.

Step 7

ⓘ This step is for replacing the keyboard only. If you are not replacing the keyboard, skip this step.

- Lay the keyboard face down.

- Remove the four 3.00mm screws that attach the keyboard to the keyboard frame.

Step 8

ⓘ This step is for replacing the keyboard only. If you are not replacing the keyboard, skip this step.

● Lift the keyboard off the keyboard frame.

To reassemble your device, follow these instructions in reverse order.