Nikon D7000 Shutter Replacement

last step in the lock exchange. shutter replace.

Written By: Charly



This document was generated on 2021-02-25 11:50:51 PM (MST).

TOOLS:

- New Item (1)

PARTS:

- New Item (1)

© iFixit — CC BY-NC-SA

Step 1 — Shutter



- If the shutter looks like that, nothing works.

Step 2



- Remove 2 screws.

© iFixit — CC BY-NC-SA

Step 3



- Pull off the flex cable and remove the 3rd screw underneath.

Step 4



- Desolder 4 solder bridges

© iFixit — CC BY-NC-SA

Step 5



- Unsolder the motor cable

Step 6





- Turn the gears to open the curtain.
- The lever is then right.
- When assembling, press the shutter lever down.

Repeat the steps in order to reassemble your device.

© iFixit — CC BY-NC-SA