

# Moen Posi-Temp Cartridge Part #1112b Replacement

Replacing the cartridge of a Moen Posi-Temp shower valve part number 1222b

Written By: John Mendoza



This document was generated on 2021-04-20 09:42:49 AM (MST).

#### INTRODUCTION

Is your shower producing inconsistent water temperature?

Before replacing the cartridge, first check a nearby faucet or shower to see if it is also getting inconsistent water temperature. If it is not, then the problem would be the valve's cartridge and would need to be replaced.

This guide will take you through the steps of replacing the cartridge of a Moen Posi-Temp shower valve.

This procedure will take you through the plumbing so make sure that you locate the main shutoff valve to the shower or to the house as you would need to turn off the water for this procedure.



#### **TOOLS:**

- Phillips #00 Screwdriver (1)
- Needle Nose Plier (1)
- Vice Grips (1)
- 3/32" Allen Wrench (1)



#### **PARTS:**

Moen 1222 Cartridge, Posi-Temp (1)

#### Step 1 — Moen Posi-Temp Cartridge Part #1112b



 Turn the water shutoff valve counterclockwise to the "off" position.

### Step 2



 Open both the hot and cold taps of a nearby faucet or shower until the water no longer flows.





Turn the handle of the shower valve 180 degrees until it is in the "up" or "on" position.

# Step 4





- Unscrew the handle screw with an Allen wrench.
- Remove the handle.





- Remove the handle adaptor screw with a Phillips screwdriver.
- Remove the handle adaptor simply by pulling it out.

# Step 6



 Pull out the white key/adjustable limit stop.







Gently pull out the stop tube.

# Step 8







- Using the Phillips head screwdriver, remove the two screws located at the top right corner and bottom left corner.
- Remove the metal plate.







• Slide the tip of needle-nose pliers under the notch of the retaining clip and pull the clip upwards.

# Step 10







Clamp firmly onto the brass tube with a pair of vice grips and gently but firmly pull out the cartridge.





Insert the new Moen Posi-Temp cartridge.

### Step 12



- Insert the new cartridge into the valve assembly.
- Ensure that the H/C symbols are facing up.
- Ensure that the notch on the brass tube is also facing up.

To reassemble your device, follow these instructions in reverse order.