




Nike+ Sportband Screen Replacement

This guide will help you to replace a cracked or damaged screen on your NikePlus Sportband.

Written By: Daniel Burtner



INTRODUCTION

This repair might be needed if your NikePlus Sportband screen has been damaged due to being drop or stepping on the device.

TOOLS:

- [Metal Spudger](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — External Case




- To begin the disassembly of your NikePlus Sportband, first remove the device from the rubber wristband.

Step 2




- Finish the disassembly of your NikePlus Sportband by utilizing the metal spudger tool on the short edge to pry the external body pieces apart.

Step 3 — Screen





- After the cover had been removed, use the metal spudger tool to remove the body of the device from the casing.

Step 4






- Use the metal tweezers to pry the screen casing from the body of the device.
- The screen casing is fastened to the body of the device by four clips located in each corner of the casing.

Step 5



- Flip the body of the device over so that the screen is now on the bottom.
 - The display ribbon cable is soldered to the motherboard. We were able to peel up the ribbon cable with a pair of tweezers.
- ⚠ Successfully resoldering this ribbon cable to the motherboard may prove difficult to the very small traces.

Step 6



- Flip the body of the device back over so that the screen is facing up.
- Using the tweezers, gently lift the screen from body of the device.

To reassemble your device, follow these instructions in reverse order.